

Easy Clean Bath Waste

Installation Procedure

1. Prior to installation check the length of the bath waste is adequate to fit your bath. Also check that your bath thickness at the overflow is no larger than 5mm and at the waste is no larger than 25mm.

2. Remove the overflow cover and fixing screw from the overflow body and assemble to the bath in the arrangement shown, (right) with the overflow washer behind the bath surface and the metal overflow bracket on the inside of the bath tub surface.

3. Ensure that the tabs in the overflow bracket are aligned horizontally so that when re-attaching the overflow cover it is positioned with the water inlet gap to the bottom. Tighten the fixing screw and fixing bracket to the overflow body.

4. Ensure that the seal between the overflow washer and the bath is tight to prevent water leakage. Silicone sealant may be used to assist this.

5. Fix the overflow cover to the overflow bracket with the tabs aligned.

6. Disassemble the waste housing from the waste body and assemble to the bath in the order shown on the diagram. There should be a washer on the underside of the bath surface and one on the inside of the waste hole assembled to the waste housing. Silicone sealant (not supplied) can be applied to ensure a water tight seal.

7. Insert the easy clean waste insert into the waste housing. Check the click-mechanism works and forms a seal when closed. This insert can be removed for cleaning and maintenance.

Installation is now complete.

MAX THICKNESS AT BATH OVERFLOW: 5MM
MAX THICKNESS AT BATH WASTE: 25MM

