


## Technical Data Sheet

## PILL COUNTERTOP BASIN

What's in the box: 1x DC12051







Diagrams not to scale All dimensions in mm Tolerance of +/-5mm

## <u>FAQ</u>s

Q: What is the maximum water depth of the basin?

Q: Can this basin be wall mounted?

Q: What ranges can this basin be used on?

Q: What are the taphole/ basin waste sizes?

Q: Where should the basin be located on the worktop?

A: Measurement not applicable. Since this basin does not have an overflow channel it should only be used with an open waste.

A. No.

A: Please see compatibility matrix in the R2 brochure.

A: All sizes are to British Standard - (BS EN 31)

- Diameter of the central tap hole = 35mm: +2/-1mm
- Bore of the waste outlet hole = 46mm: +2 / 3mm

A: We recommend it being centralised on the worktop left to right. Front to back should be set based on desired tap location and waste outlet.

## Furniture units compatibility

Туре		Status			Contour		Platform			
500	600	500	600	800	500	600	500	600	700	800
No	Yes	No	Yes	Yes	No	Yes	No	Yes	Yes	Yes

<sup>\*\*</sup>Dimensions are subject to change, customers are advised to measure actual product before commencing installation.

<sup>\*\*\*</sup> BASIN HAS NO OVERFLOW SO MUST BE USED WITH AN OPEN WASTE