ROPER RHODES®

Unity 2F Concealed Shower Valve CH - SV3906


| No. | Description | Code | Fixings Included |
|-----|------------------------------------|--------|------------------|
| 1 | Unity 2F Concealed Shower Valve CH | SV3906 | YES |




| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SV3906





FAQs Components

What is included in the valve box? The valve, a cover plate, a set of handles and trim rings.

What is the size of the connections? The valve uses 1/2" connections.

What is the recomended operating pressure? 1.0bar

Valve - RR18

Chrome Valve Plate - SVCOMP7

Chrome Valve Handle - SVHANUN

ROPER RHODES®

Unity 2F Concealed Shower Valve B - SV3915


| No. | Description | Code | Fixings Included |
|-----|-----------------------------------|--------|------------------|
| 1 | Unity 2F Concealed Shower Valve B | SV3915 | YES |




| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SV3915





FAQs Components

What is included in the valve box? The valve, a cover plate, a set of handles and trim rings.

What is the size of the connections? The valve uses 1/2" connections.

What is the recomended operating pressure? 1.0bar

Valve - RR19

Black Shower Plate - SVCOMP8

Black Valve Handle - SVHANUN.B

ROPER RHODES®

Unity 2F Concealed Shower Valve B - SV3919


| No. | Description | Code | Fixings Included |
|-----|---------------------------------------|--------|------------------|
| 1 | Unity 2F Concealed Shower Valve Brass | SV3919 | YES |




| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SV3919





FAQs Components

What is included in the valve box? The valve, a cover plate, a set of handles and trim rings.

What is the size of the connections? The valve uses 1/2" connections.

What is the recomended operating pressure? 1.0bar

Valve - RR20

Brass Shower Plate - SVCOMP18

Brass Valve Handle - SVHANUN.BR

ROPER RHODES®

Unity 2F Concealed Shower System Chrome - SVSET151


No.DescriptionCodeFixings Included1Unity 2F Concealed Shower System ChromeSVSET151YES



| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SVSET151



FAQs Components

What is the size of the connections? The valve uses 1/2" connections.

What size Pipework do i need? 15mm

Is it suitable for stud walls? It is recomended you use CLS size 89mm depth within the wall

Does the valve include isolation points? Yes

What is the recomended operating pressure? 1.0bar

Valve - RR18

Chrome Shower Plate - SVCOMP7

Chrome Valve Handle - SVHANUN

Riser rail - SVRAIL09

Handset - SVHEAD43

Easy Clean PVC Shower Hose - SVHOSE02

Brass Wall Elbow - SVACS03

Adjustable Fixed arm - SVARM01

Stainless Steel Shower Head - SVHEAD12

ROPER RHODES®

Unity 2F Concealed Shower System Black - SVSET152


| No. | Description | Code | Fixings Included |
|-----|--|----------|------------------|
| 1 | Unity 2F Concealed Shower System Black | SVSET152 | YES |



| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SVSET152



FAQs Components

What is the size of the connections? The valve uses 1/2" connections.

What size Pipework do i need? 15mm

 $\mbox{\sc ls}$ it suitable for stud walls? It is recomended you use CLS size 89mm depth within the wall

Does the valve include isolation points? Yes

What is the recomended operating pressure? 1.0bar

Valve - RR19

Black Shower Plate - SVCOMP8

Black Valve Handle - SVHANUN.B

Riser rail - SVRAIL10

Handset - SVHEAD44

Easy Clean PVC Shower Hose - SVHOSE04

Brass Wall Elbow - SVACS18

Adjustable Shower arm - SVARM12

Stainless Steel Shower Head - SVHEAD46

ROPER RHODES®

Unity 2F Concealed Shower System Brass - SVSET173


| No. | Description | Code | Fixings Included |
|-----|--|----------|------------------|
| 1 | Unity 2F Concealed Shower System Brass | SVSET173 | YES |



| Inlet Pressure | Flow Rate (I/min) |
|----------------|-------------------|
| 1bar | 11.6 |
| 2bar | 17.0 |
| 3bar | 21.0 |

Flow from valve may vary depending on accessories and domestic supply.

Dimensions - SVSET173



FAQs Components

What is the size of the connections? The valve uses 1/2" connections.

What size Pipework do i need? 15mm

 $\mbox{\sc ls}$ it suitable for stud walls? It is recomended you use CLS size 89mm depth within the wall

Does the valve include isolation points? Yes

What is the recomended operating pressure? 1.0bar

Valve - RR20

Brass Cover Plate - SVCOMP18

Brass Valve Handle - SVHANUN.BR

Riser rail - SVRAIL14

Handset - SVHEAD53

Hose - SVHOSE05

Brass Wall Elbow - SVACS27

Adjustable Shower arm - SVARM16

Stainless Steel Shower Head - SVHEAD52