
# Technical Data Sheet


# ROPER RHODES®


## **VECTOR 600mm WALL MOUNTED UNIT**

What's in the box: 1x VECTOR 600mm + Fixings

\*Reference basin TDS for further info







#### **Materials**

Carcass: 18mm MDF and MFC Facia Components: 18mm MDF Shown with the Frame isocast basin Diagrams not to scale All dimensions in mm Tolerance of +5mm

### Extra Dimensions

Internal Drawer Depth - Front to Back:

Internal Drawer Height:

Internal Drawer Width:

Drawer Cut Out (W&D):

Hanger Centres:

Front of drawer cut outs to back of unit?

324mm

147mm 515mm

150mm Wide & 240mm Deep

540mm

267mm

#### **FAQs**

Q: Are the runners soft close?

Q: Can the drawers be adjusted?

Q: What is the interior finish of the unit?

Q: Does the unit have a RAL reference?

Q: What is the weight capacity of the drawer?

Q: Is the wall hanging mechanism the only fixing to the wall?

Q: How deep is the unit when the drawers are fully open?

Q: Why is the push-to-open drawer not opening when pushed?

Q: Can other basin or worktop combinations be fitted?

A: The runners are both soft close and quick release.

A: Approx. 746mm

A: The drawers can be adjusted as detailed in the supplied instructions.

A: The unit interior is the same finish as the exterior.

A: No, part can be taken and matched by paint supplier (no RAL code)

A: The weight capacity of the drawer is 15kg.

A: No, it is advised to apply additional fixings to the wall through allocated holes in the back brace. Fixings for this are included.

A: The push to open mechanism may not be correctly adjusted. Refer to the Push To Open Adjustment section of the Vector WM instructions.

A: Yes. See compatibility table below.

Collection	Frame	Scheme
Ceramic basins	✓ FRM600C	✓ SCH600C
Isocast basins	✓ FRM600IS	✓ SCH600IS
Solid surface worktop	×	✓ SCH6SSWKIT
Vessel basins	×	✓ VCR2/ VCR1/ VSS3

NOTE: Colours unique to Roper Rhodes - No RAL Code available

<sup>\*\*</sup>Dimensions are subject to change, customers are advised to measure actual product before commencing installation.

<sup>\*\*\*</sup>Fixing point dimensions are for guidance only/the positions of wall fixing must be checked when product is received.